

Instruction manual item 4349906 , PO 0912117

A. BATTERY INSTALLATION

Turn to the product backside and insert the battery 1*1.5V AA with the terminals as shown .

B. SETTING THE TIME

Turn the hour/minute control clockwise

C. REGULATE THE SECONDS

Remove the battery to stop the second hand .

Insert the battery again when second works in correct place in order to restart the clock.

NOTE:

- This clock is designed to not deviate by more than a few minutes over a year .
- Replace the battery if the time suddenly begins fluctuating . Remove the battery if the clock is not being used .

Cleaning: Use a dry cloth for cleaning when necessary. Do not dip in water or other liquids and do not use corrosive cleanser.

Disposal of waste: The item has to be disposed according to the waste disposal regulations valid in your country. Paper and carton are for waste-paper, foil is for Yellow Bin.



reg.no.: 72005675

Easy Gifts GmbH, Thomas-Mann-Str.60, DE-90471 Nürnberg

Betriebsanleitung Artikel 4349906, PO 0912117

A. Einlegen der Batterie

Legen Sie die 1.5V-Batterie den Polen entsprechend in das Batteriefach auf der Rückseite der Uhr.

B. Uhrzeit einstellen

Drehen Sie die Stunden-/Minutenrädchen im Uhrzeigersinn, um die Uhrzeit einzustellen.

C. Sekunden einstellen

Entfernen Sie die Batterie, um den Sekundenzeiger anzuhalten. Legen Sie sie wieder ein, wenn sich der Sekundenzeiger an der korrekten Position befindet, um die Uhr wieder in Gang zu setzen.

- **ACHTUNG:** Bitte beachten Sie, dass diese Uhr so konzipiert wurde, dass sie pro Jahr nicht mehr als wenige Minuten pro Jahr nachgeht.
- Wechseln Sie die Batterie wenn die Uhrzeit plötzlich abweichen sollte. Entfernen Sie die Batterie bei Nichtgebrauch.

Reinigung: Bei Bedarf mit einem trockenen Tuch reinigen.

Nicht in Wasser oder andere Flüssigkeiten tauchen und keine scheuernden oder ätzenden Reinigungsmittel verwenden.

Entsorgung: Entsorgen Sie den Artikel nach den in ihrem Land geltenden Vorschriften

Papier/Pappe gehören zum Altpapier, Folien in die Wertstoffsammlung

Batterien / Akkus gehören nicht in den Hausmüll und müssen bei einer Sammelstelle der Stadt, Gemeinde oder im Handel abgegeben werden.



reg.no.: 72005675

Easy Gifts GmbH, Thomas-Mann-Str.60, DE-90471 Nürnberg